

TIME MANAGER® INSTRUCTIONS

No more line tangles or checking your lines again...

- Small, flexible, lightweight
- Clips onto your kite bar for easy storage
- Keeps lines organized/untangled
- Reduces rigging area by 90% and rigging time by 70%
- Ideal for small/challenging launch areas including boat launches
- Conveniently fits in a pocket when riding

For more information and video,
go to www.kitelauncher.com
or
email sales@kitelauncher.com


*Warranty/Disclaimer: This product is guaranteed against breakage for one (1) year and is fully replaceable. You should never have to untangle your lines again if you follow this sequence and make a habit of using the Time Manager. Liquid Sky Kiteboarding LLC is not liable if product is used other than instructed.



FIRST TIME TIP: Before using your Time Manager®, bend to open up the notches so the lines snap into place easier!

HOW TO LOAD THE TIME MANAGER®

1 After a session, place bar downwind of kite with lines fully laid out. If space is limited, wrap lines up in figures 8's around your bar first. Do not half hitch lines at any time. Snap lines into the small notches of the TM approximately 3 feet (1 meter) from pigtails, in exactly the same order that they attach to kite, i.e. trailing edge lines on the outside and leading edge lines on the inside. If you have a 5th line, it goes in the middle notch. Make sure you don't cross the lines! Once the lines are in place, pull all lines together so they are exiting through one side of the TM. You can now disconnect your lines from your kite.



2 Neatly gather lines together at your bar with no crossovers just above the trim system to create a triangle.



3 From the tip of the triangle at the gathering point, start wrapping lines in figure 8's firmly, starting at either bar end. Make sure chicken loop and trim system are free of bar and lines.



4 Continue figure 8 wraps until you reach the TM. Then, just clip it onto your bar or lines and wrap the rest of the lines around your bar. Secure remaining lines in whatever way you prefer.



HOW TO RIG YOUR KITE

1 Unwrap 3 feet (1 meter) of lines from bar to the TM. Attach lines to the kite only after making sure they are uncrossed/untangled and referenced to your kite attachment points. (these are usually color coded by the kite manufacturer).



2 Once lines are attached to the kite, remove the TM from your lines. Walk your lines out from your bar downwind of kite (remember that your bar is upside down and never take your bar under or over the kite).

3 Give the bar and lines tension, and take one last visual check to make sure that your lines are not crossed or tangled before launching your kite.